NUMBER THIRTY-SIX (VOLUME TWO)

THE Philips Model 580A is 5-valve (plus valve rectifier) A.C. superhet, with a circuit and chassis very similar to that of the Model 588 A (Service Sheet No. 26, Vol. I). are, however, several modifications, notably a change from choke to resistance smoothing, an alteration in the gramophone pick-up circuit and the elimination of the variable tone control circuit.

CIRCUIT DESCRIPTION

Signal input by way of I.F. rejector circuit L1, C20 and series condenser C1 to capacity-coupled band-pass filter. Primary L2, L3 tuned by C21; secondary L4, L5 tuned by C23; coupling condensers C2, C3.

First valve (V1, Mullard metallised FC4) is an octode operating as frequencychanger with electron coupling. Oscillator grid tuning coils **L6**, **L7** tuned by **C25**; anode reaction coils **L8**, **L9**; tracking by fixed condensers **C5** (L.W.) and **C6** (M.W.).

One variable-mu pentode intermediate requency amplifier (V2, Mullard metallised VP4A) with tuned-primary tuned-secondary transformer couplings L10, L11 and L12, L13.

Intermediate frequency 115 KC/S.

Half-wave diode second detector forming part of double diode valve (V3, Mullard metallised 2D4A). Steady voltage developed across load resistances R7, R8 by reason of the carrier waves of a transmitter is fed back via decoupling circuits as G.B. to frequency changer and I.F. valves, giving automatic volume control.

Audio-frequency component in output from rectifier is tapped off by manual volume control R8 and passed by way of

IPS 580A A.C. SUPERHET

coupling condenser C11 to pentode L.F. amplifier (V4, Mullard metallised SP4). Provision for connection of gramophore pick-up across volume control.

Resistance - capacity coupling to directly-heated output pentode (V5, Mullard PM24M). Fixed tone compensation by condenser C17 across primary of speaker input transformer T1.

H.T. current supplied by full-wave rectifying valve (V6, Philips 1821). Smoothing by resistance R14 and largecapacity electrolytic condensers C15,

DISMANTLING THE SET

Removing Chassis .- Remove the three knobs (grub screws fitting into slots in spindles). Unsolder speaker earth-lead from speaker. Unclip speaker cable from side of cabinet. Remove four screws from underside of cabinet which hold the chassis. These screws pass through tubular distance pieces, fitted with rubber bushes. When replacing do not forget the contact strip clamped by one of the screws between the chassis and the metal foil lining to the cabinet.

Chassis may now be withdrawn sufficiently for normal repair work. To free it entirely, unsolder the two leads in the speaker cable from the tags on the speaker transformer.

Removing Speaker.—This is held to its sub-baffle by three clips, with bolts, nuts and lock nuts. When replacing the transformer should be at the top.


COMPONENTS AND VALUES

	Resistances			Values (ohms)
Rı	VI cont. grid decouplin	g		10,000
R2	VI fixed G.B. resistance	9		200
R ₃	Vi osc. grid resistance			50,000
R4*	VI, V2 and V4 S.G.'s I	I.T.	. feed	32,000
R5	V2 fixed G.B. resistance			2,000
R6	V2 cont. grid decoupling	g		1,000,000
R7	Part of diode load	_		250,000
R8	Manual volume control			500,000
Rg	V ₄ grid resistance			1,000,000
Rio	V ₄ anode resistance			320,000
RII				6,400
RI2	V ₅ grid H.F. stopper			640,000
R13	Mar model and delicated and			500,000
R14	H.T. smoothing			2,500
R15	V ₅ G.B. resistance			640
R161	Volume control shunt			1,000,000

* Two 64,000 O resistances in parallel. † Or 640 O. ‡ In our chassis.

Condensers	Values (μF)
C1	0.000025 0.025 0.025 0.005 0.00093 0.00181 0.5 0.1 0.1 0.01 0.0001 0.01 0.0002 25.0 0.001 32.0 1.0

* In metal "can." (Continued overleat)



For more information remember www.savov-hill.co.uk

DI


PHILIPS 580A A.C. SUPERHET (continued)

Condensers (contd.)	Values (µF)
C18 C19 C19 C20 LF. rejector tuning, pre-set C21 Band-pass primary tuning C23 Band-pass secondary tuning C24 Band-pass secondary tuning C25 Oscillator grid tuning C26 Oscillator grid tuning C27 C28 C29 C30 C30 C30 C30 C31	32.0 25.0 0.000145 0.00043 0.000055 0.00043 0.000055 0.00043 0.000055 0.000055 0.0000145 0.000145 0.000145

Other Components		Values (ohms)
L1 L2 L3 L4 L5 L6 L7 L8 L9 L11 L12 L13 L14 T1	Aerial I.F. rejector coil	(ohms) 127·0 3·9 36·8 3·9 36·8 9·75 27·4 4·1 10·7 135·0 135
S ₅ -S ₆	Mains switches	•

VALVE ANALYSIS

The voltage and current readings listed in the table below are those given by Philips for an average chassis working with no aerial or earth connected. All voltages were measured with a high resistance voltmeter, the chassis being negative, and the anode currents of V1 and V2 were taken with a milliammeter inserted in the low H.F. potential ends of the circuits. As an alternative to this method of ensuring stability during measurements the valves may be



Plan view of the chassis. C15 and C18 are electrolytics, while C7 and C16 are two paper condensers in a single can.

stabilised by means of condensers (o.1 μF or larger) connected between their anodes and cathodes.


Valve	Anode Volts	Anode Current (mA)	Screen Volts	Screen Current (mA)
V ₁ FC ₄ * V ₂ VP ₄ A V ₃ 2D ₄ A V ₄ SP ₄ V ₅ PM ₂ 4M V ₆ 1821	235 235 — 140 230 225†	0·8 2·0 — 0·3 22·6	65 65 65 220	2·5 1·0 — 0·12 4·25 —

* Osc. anode (G2) 65 V 1.25 mA. † A.C., each anode.

GENERAL NOTES

In the majority of cases the notes given on pages 32 and 33 of Sheet No. 26, Vol. I, will be applicable also to the Model 580A under consideration, but as a certain amount of re-numbering of components has occurred, the numbers do not necessarily correspond.

Switches.—There are four waveband switches, **S1-S4**, and a two-pole mains switch, **S5**, **S6**. These two groups are ganged by a lever. **S5** and **S6** are shown in our under-chassis view, while the **S1-S4** assembly is shown in the form of a diagram below. All the wavechange



The wavechange switch assembly. S₃ is below S₂.

switches are closed on the M.W. band and open on the L.W. band.

Coils.—The signal frequency and oscillator coils are mounted in three "cans" on top of the chassis, whilst the I.F. coils are in two similar "cans" below the chassis. Since the screens are not removable, it will be advisable, in case of coil trouble, to fit new units. The units are easily removable from the chassis.

Dial Lamp.—This is a 6 V 3W car type, with a centre contact S.B.C. base.

Condensers C7, C16.—These are in a single can on top of the chassis. Three connecting tags project downwards through the chassis. The common tag is that which is earthed to chassis. The tag connected to the screening grids of V1, V2, V4 is the other terminal of C7, while that connected to the screening grid of V5 is the other terminal of C16.

Circuit Alignment.—The instructions given in Sheet No. 26 can be followed, bearing in mind the different numbering of the components. All the condensers involved in the trimming operations now have numbers two less than in Sheet 26. Thus C25 is now C23, and C33 is now C31.



The under-chassis view. S5 and S6 are indicated, and are ganged with the wavechange switch assembly, shown in a sketch on this page.