'TRADER' SERVICE SHEET

214

BUSH DAC43.

DUG43, RG43

A SHORT-WAVE range of 17-53 metres is covered by the Bush DAC₄₃ 4-valve A.C./D.C. 3-band superhet. Suitable for mains of 180-260 V (40-80 C/S in the case of A.C.), it employs a Westinghouse unit for rectification on A.C. supplies and has provision for both a gramophone pick-up and an extension speaker, a plug and socket arrangement allowing the internal speaker to be cut out, if desired.

A very similar chassis is fitted in the DUG43 console receiver and a slightly modified one in the RG43 radio-gramophone and automatic radio-gramophone, but this Service Sheet was prepared on a DAC43 table receiver.

CIRCUIT DESCRIPTION

Aerial input via blocking condenser C1 and on M.W. and L.W. via coupling coils L1 (M.W.) and L3 (L.W.) to capacity coupled band-pass filters. Primaries L2 (M.W.), L4 (L.W.) are tuned by C37; top coupling by small condensers C4 (M.W.), C5 (L.W.) and bottom coupling by C3. On S.W. band aerial input is via coupling coil L5 to single tuned circuit comprising L6 and the condensers C4 (M.W.).

tuning condenser C37.

First valve (V1, Mullard metallised TH21C) is a triode-hexode operating as a frequency changer with internal coupling. Oscillator grid coils L9 (S.W.), L11 (M.W.) and L13 (L.W.) are tuned by C38; parallel trimming by C39 (S.W.), C40 (M.W.) and C12, C42 (L.W.); series tracking by C10 (S.W.), C11, C41 (M.W.) and

 $\pmb{\text{C43}}$ (L.W.); oscillator anode reaction coils $\pmb{\text{L10}}$ (S.W.), $\pmb{\text{L12}}$ (M.W.) and $\pmb{\text{L14}}$ (L.W.).

Second valve is a variable-mu R.F. pentode (V2, Mullard metallised VP13C), operating as intermediate frequency amplifier with special triple-tuned transformer couplings C44, L15, L16, C45, L17, C46 and C47, L18, L19, C48, L20, C49.

Intermediate frequency 465 KC/S.

Diode second detector is part of double diode triode valve (V3, Mullard metallised TDD13C). Audio-frequency component in rectified output is developed across load resistance R14 and passed via coupling condenser C21 and manual volume control R12 to C.G. of triode section of V3 operating as A.F. amplifier. Provision for connection of gramophone pick-up across R12 via mains isolating condensers

C19 and C20.

Second diode of V3, fed from V2 anode via C24, provides D.C. potential which is developed across R19 and fed back through decoupling circuits as G.B. to F.C. and I.F. valves, giving automatic volume control. Delay voltage is obtained from drop along V3 cathode resistance R17.


Resistance capacity coupling by R16, C25, R21, R22 between V3 triode and pentode output valve (V4, Mullard Pen36C). S21 opens on S.W. and provides tone adjustment. Variable tone control by R.C. filter C26, R25 in anode circuit. Provision for connection of low impedance external speaker across secondary of internal speaker transformer T1. Plug and socket arrangement enables internal speaker speech coil circuit to be broken.

When the receiver is used with A.C. mains, H.T. current is supplied by a half-wave metal rectifier (MR1, Westinghouse B27) which, with D.C. supplies, behaves as a low resistance. Smoothing is effected by iron-cored choke L22 and dry electrolytic condensers C28. C29.


dry electrolytic condensers C28, C29. Valve heaters are connected in series together with scale lamps and current regulating barretter lamp (Philips C1), across mains input circuit. Filter comprising chokes L23, L24 and condenser C30 suppresses mains-borne interference.

COMPONENTS AND VALUES

	RESISTANCES	Values (ohms)
Rı	VI hexode C.G. decoupling	1,000,000
R ₂	VI hexode S.G's H.T. potential	20,000
R ₃		20,000
R ₄	V ₁ hexode anode and V ₂ anode	
· ·	decoupling	5,000
R ₅	Vr fixed G.B	100
R6	VI osc. C.G. resistance	30,000
R7	V1 osc. anode decoupling	15,000
R8	V2 C.G. stabilising resistance	250
Rg	V2 C.G. decoupling resistance	1,000,000
Rio	V2 S.G. decoupling	50,000
RII	V2 fixed G.B. resistance	100
R12	Manual vol. control	500,000
R13	I.F. stopper	200,000
R14	V3 signal diode load	1,000,000
R15	V ₃ triode anode decoupling	10,000
R16	V3 triode anode load	50,000
R17	V3 G.B. resistance	1,000
R18	A.V.C. line decoupling	1,000,000
Rig	V3 A.V.C. diode load	1,000,000
R20	V4 C.G. I.F. stopper	100,000
R21	1	100,000
R22	V4 C.G. resistances	550,000
R23	V4 C.G. I.F. stopper	100,000
R24	V4 G.B. resistance	350
R25	Variable tone control	50,000



Under-chassis view. The whole of the coil unit on the right is not shown, as all the components in it are identified in the side - chassis view on page VIII. Note the six condensers beneath the horizontal component panel, which are in a single metal case, which forms one common connection to each condenser. The tags forming the other connections are indicated.



THE WIRELESS TRADER

	CONDENSERS	Values (μF)
Cı	Aerial blocking condenser	0.004
C ₂	Earth blocking condenser	0.005
C ₃	Band-pass bottom coupling	0.005
C4	Band-pass M.W. top coupling	0.03
C ₅	Band-pass L.W. top coupling	Very low
C6	VI hexode S.G.'s by-pass	Very low
C7	VI cathode by-pass	0.1
C8	Vr osc. C.G. condenser	0.1
Co	VI, V2 anodes decoupling	0.00005
Cio	Osc. S.W. tracker	0.1
CII	Osc. M.W. fixed tracker	0.0043
CI2	Osc. L.W. fixed tracker	0.0004
Cr3	VI osc. anode decoupling	0.0001
C14		0.1
Crs		0.1
C16	V2 S.G. decouping	0.1
C17*	V2 cathode by-pass	0.1
C18	V3 triode anode decoupling	2.0
Cig	I.F. by-pass	0.0001
C20	Pick-up isolating condensers	0.03
C21	,	0.1
C22	A.F. coupling to V3 triode	0.005
C23*	V3 signal diode coupling	0.0001
C24	V3 cathode by-pass	50.0
	V ₃ A.V.C. diode coupling	0.0001
C25	V3 to V4 A.F. coupling	0.03
	Part of T.C. filter	0.03
C27*	V4 cathode by-pass	50.0
C28*	H.T. smoothing	16.0
C29*	()	24.0
C30	Mains R.F. by-pass	0.01
C31‡	Band-pass M.W. pri, trimmer Band-pass L.W. pri, trimmer	0.000035
C32‡	Band-pass L.W. pri. trimmer	0.000035
C33†	Band-pass pri, tuning	
C34‡	Aerial S.W. trimmer	0.000035
C35‡	Band-pass M.W. sec. trimmer	0.000035
C36‡	Band-pass L.W. sec. trimmer	0.000035
C37†	Band-pass sec. tuning	
C38†	Osc. circuit tuning	
C39‡	Osc. S.W. trimmer	0.000035
C40‡	Osc. M.W. trimmer	0.00008
C ₄ I [‡]	Osc. M.W. tracker	0.0003
C42‡	Osc. L.W. trimmer	0.00008
C43‡	Osc. L.W. tracker	0.0003
		- 5503

	Values (μF)		
C44: C45: C46: C47: C48: C48: C49:	Ist I.F. trans. pri. tuning Ist I.F. trans. tert. tuning Ist I.F. trans. sec. tuning 2nd I.F. trans. pri. tuning 2nd I.F. trans. tert. tuning 2nd I.F. trans. sec. tuning		0.00015 0.00015 0.00015 0.00015 0.00015

* Electrolytic. † Variable. ‡ Pre-set.

	OTHER COMPONENTS	Approx. Values (ohms)
L1 L2 L3	Aerial M.W. coupling coil Band-pass M.W. primary coil Aerial L.W. coupling coil	0·7 2·4
L ₄	Band-pass L.W. primary coil	15.5
L ₅	Aerial S.W. coupling coil	7.4
Lő	Aerial S.W. tuning coil	0.05
L7	Band-pass M.W. secondary coil	2.4
L8	Band-pass L.W. secondary coil	7.4
Lg	Osc. S.W. tuning coil	0.05
Lio	Osc. S.W. reaction coil	0.2
LII	Osc. M.W. tuning coil	1:5
L12	Osc. M.W. reaction coil	1.25
LI3.	Osc, L.W. tuning coil	2.45
L14	Osc. L.W. reaction coil	2.0
L15) (Primary	7.0
L16	rst I.F. trans. Tertiary	7.0
Li7	Secondary	7.0
L18	Primary	7.0
L19	2nd I.F. trans. Tertiary	7.0
L20	Secondary	7.0
L21	Speaker speech coil	1.7
L22	H.T. smoothing choke	160.0
L23	Mains filter chokes {	6.0
L24	()	6.0
Ti	Speaker input trans. { Pri.	600.0
SI-S21	Sec.	0.2
S22-24	Wavechange switches	
S25,26	Scale lamp switches	
543,20	and switches, ,	

DISMANTLING THE SET

Removing Chassis .- If it is desired to remove the chassis from the cabinet, first remove the five control knobs (recessed grub screws) and then remove the insulating covering for the heads of the four chassis fixing bolts (eight round-head wood screws) and remove the bolts (with washers).

Now free the speaker and mains switch leads from the cleats holding them to the side of the cabinet, when the chassis can be withdrawn to the extent of the leads.

To free the chassis entirely, remove the mains switch unit from the side of the cabinet (four round-head wood screws) and unsolder the speaker leads. When replacing, connect the leads as follows, numbering the tags from bottom to top :-1, red; 5, yellow.

Removing Speaker.—The speaker may be removed from the cabinet by unsoldering the leads and removing the nuts (and washers) from the four bolts holding it to the sub-baffle. When replacing, see that the terminal panel is on the right and connect the leads from the chassis and mains switch unit as above, and the leads from the extension speaker panel as follows:—2, green; 3, brown; 4, black. The black lead from the mains switch unit goes to the earthing tag on the speaker.

Continued overleaf

BUSH DAC43 - Continued

VALVE ANALYSIS

Valve voltages and currents given in the table below are those measured in our receiver when it was operating on A.C. mains of 225 V. The receiver was tuned to the lowest wavelength on the medium band and the volume control was at maximum, but there was no signal input.

Voltages were measured on the 1,200 V scale of an Avometer, chassis being negative.

Valve	Anode Voltage (V)	Anode Current (mA)	Screen Voltage (V)	Screen Current (mA)
V1 TH21C*	185	2.5	65	5.8
V2 VP13C	185	6.0	100	2.2
V ₃ TDD ₁₃ C	90	2.2		_
V ₄ Pen 36C	215	33.0	235	4.7

* Oscillator anode 140 V, 7.4 mA.


GENERAL NOTES

Switches.—\$1-\$21 and \$22-\$24 are the waveband and scale lamp switches, ganged in three rotary units beneath the chassis. The units are indicated in our side-chassis view, and are shown in detail in the diagrams on page V, as seen looking at the underside of the chassis from the rear. The table (p. V) gives the switch positions for the three control settings, starting from fully anti-clockwise. O indicates open, and C, closed.

\$25 and **\$26** are the Q.M.B. mains switches, in a single unit, mounted on the separate mains input panel, with **L23**, **L24** and **C30**.

Coils.—The signal frequency and oscillator coils, **L1-L14**, are in a partitioned screened unit, with the wavechange switches and several other components.

Side-chassis view, showing the coil and switch assembly with its metal side-plate removed. Note the two small condensers C4, C5. Each of the eight coil formers carries one or two coils, and a trimmer mounted at its front end.



This unit projects above and below the chassis deck. The coils are indicated in detail in our side-chassis view, the metal side plate of the unit having been removed. In all there are eight coil formers, each carrying one or two coils, and each having a trimmer mounted at its end.

The I.F. transformers, **L15-L17** and **L18-L20**, are in two screened units on the chassis deck. Note that each contains three coils and three trimmers. The trimmers are adjustable through holes in the backs of the cans, and in our plan chassis view, they are numbered from top to bottom in each case.

Scale Lamps.—These are three Ever Ready M.E.S. types, rated at 6.2 V, 0.3 A. They are switched by **\$22-\$24**.

External Speaker.—Provision is made, by a panel at the top of the back of the cabinet, for the use of a low impedance (about 2 O) external speaker. The internal speaker speech coil may be disconnected by a plug and socket device, also on the panel.

Condensers C17, C23, C27.—These are

three dry electrolytics in a single container, mounted on the chassis deck, and having a common negative (black) lead. The red lead is the positive of $\mathbf{C17}$ (2 μF), the yellow lead to $\mathbf{V3}$ cathode the positive of $\mathbf{C23}$ (50 μF), and the yellow lead to $\mathbf{V4}$ cathode the positive of $\mathbf{C27}$ (50 μF).

Condensers C28, C29.—These are two dry electrolytics in a single carton with a common negative (black) lead. The yellow lead is the positive of C28 (16 μ F) and the red the positive of C29 (24 μ F).

Condensers 06, 09, 013, 014, 015, 016. —These are six on 01 01 paper types in a metal case, mounted beneath one of the component strips. The case forms one common connection, and the tags indicated in the under-chassis view belong one to each condenser.

Condensers C41, C43.—These two preset condensers are mounted in a single unit, adjustable by two screws at the rear of the chassis.

Condensers C4, C5.—These are two very small fixed condensers, formed of spirals of wire wound round straight in-

sulated wires. They are indicated in the side-chassis view.

Speaker.—This is a Rola 8ZA, 9·5 PMP.

Continued on page V

Plan view of the chassis, with a side view of the mains input panel on the right. The I.F. trimmers are at the backs of the I.F. units, as indicated by the arrows, and they are numbered from top to bottom.

Printed in Great Britain as a supplement to The Wireless Trader for the proprietors and publishers, The Trader Publishing Co., Ltd., Dorset House, Stamford Street, London, S.E.I, by Sanders Phillips & Co., Ltd., The Baynard Press, Chryssell Road, London, S.W.9. Every Saturday.

BUSH DAC43 Continued

Radiogram Modifications. — In the radiogram model, RG43, the chassis is basically the same, but there are certain additions and modifications.

In the first place, there are four switch positions instead of three, Gram. being fully clockwise. An additional switch unit, outside the coil assembly, is included, while switch units 1 and 2 are modified. The effect of the modifications is to switch all scale lamps "off" on Gram.; to short C37 on Gram. (thus muting radio); to close \$21 on Gram. as well as on M.W. and L.W.: and to disconnect C21 and connect C19 to the top of R12 on Gram., and vice-versa on S.W., M.W. and L.W.

The switch **\$21** is transferred to one side of the additional switch unit, while the other side of this unit is used for the pickup switching. There are also other minor modifications.

The isolating condenser C20 is omitted (C19 being retained) and the bottom pick-up tag goes direct to chassis. pick-up arm and screening goes to true earth, not chassis. The motor frame also goes to true earth. R10 becomes 100,000 O (not 50,000 O).

The speaker is a Rola F10 13/P.M. T1 has a primary resistance of 750 O and a secondary of 0.5 O. L21 has a resistance of 1.6 O. In early models the speaker may be a Rola G12 P.M.

CIRCUIT ALIGNMENT

I.F. Stages .- Switch set to L.W., turn gang condenser to maximum, and connect signal generator to control grid (top cap) of V1, and chassis. Feed in a 465 KC/S signal, and adjust C49, C48 C47 and C46, C45, C44 for maximum

output in each case, keeping the input low. C48 is very critical.

THE WIRELESS TRADER

H.F. and Oscillator Stages. Connect signal generator to A and E sockets, via a suitable dummy aerial, which may consist of an inductance of 20 µH, a capacity of 200 µµF and a resistance of 15 O in series on M.W. and L.W., and a 400 O resistance only on S.W. See that with gang at maximum, pointer reads 550 and 2,000 m. on scale.

S.W .- Switch set to S.W. feed in an 18 m. signal. Set pointer to 18 m. on scale and adjust **C39** for maximum output. Two peaks will be obtained, that which requires the lesser trimmer capacity being correct. Next adjust C34 for maximum output.

M.W.-Switch set to M.W., feed in a 200 m. signal, tune to 200 m. on scale. and adjust C40 for maximum output on the peak requiring the lesser trimmer

SWITCH TABLE


Switch S.W. M.W. L.W. S1 C O O S2 O C O S3 O O C S4 C O O S5 C C O S6 O C O S7 O O C S8 C O O S9 O C O S10 O C O S11 C O O S12 O C O S13 O O C S14 C O O S14 C O O S16 C O O S17 O C O S18 C O O S20 O O C S21 O O C				
S1	Switch	S.W.	M.W.	L.W.
S2 O C O S3 O O C S4 C C O S5 C C O S6 O C O S7 O O C S8 C O O S9 O C O S10 O O C S11 C O O S12 O C O S13 O O C S14 C O O S15 O C O S16 C O O S17 O C O S18 C O O S29 O O C S21 O C O S22 C O O S23 O C O	Sı	C	0	0
\$\frac{53}{54} & \text{C} & \text	S2	O	C	O
\$\begin{array}{c ccccccccccccccccccccccccccccccccccc	S ₃	O	0	C
S55	S4	C	0	0
\$6	55	C	C	0
S7 O O C S8 C O O S10 O O O S11 C O O S12 O C O S13 O O C S14 C O O S15 O C O S16 C O O S18 C O O S19 O C O S20 O O C S21 O C O S22 O O O S23 O C O S24 O O C	S6	0	C	0
S8	57	O	0	C
\$90	. 58	C	0	0
S10	29	ŏ	C	0
S112 O C O O		õ	0	C
S12	511	č	0	0
S14		ŏ	Ö	2
S14	Sti	ď	ŏ.	C
S16	S14	ŏ		8 1
S17	S16	ď	ŏ	0 1
S18	Str	ŏ	ď	8 1
\$19	S18	Č	ŏ	ŏ
S20		ŏ	ď	ő
S21 O C C S23 O C O S24 O C C	S20	ŏ	ŏ	č
S22	S21	0	C	č
S23 O C O C	S22	C	ŏ	ŏ
S24 O O C	S23	ŏ	Č	ŏ
	S24	O	ŏ	Č
			-	

capacity. Feed in a 300 m. signal, tune to 300 m. on scale, and adjust C31 and C35 for maximum output. Feed in a 500 m. signal, tune to 500 m. on scale, and adjust C41 for maximum output. Check again on 300 m.

L.W.—Adopt procedure as for M.W., but adjust C42 on 1,000 m., C32 and C36 on 1,500 m. and C43 on 1,800 m. Check again on 1,500 m.

SWITCH DIAGRAMS

Switch disgrams, looking from the rear of the underside of the chassis. The units are numbered as in the sidechassis view.



MAINTENANCE PROBLEMS - continued

Hum in Philips 838U

NOTICE that a number of engineers NOTICE that a number of chigh have written with regard to the high pitched hum which develops on Philips 838U receivers. This trouble caused me a number of hours' work, and I have found it is useless just re-soldering the top of the Pen26 as this only makes a temporary repair.

The real cure is to run the solder from the top of the valve, thoroughly clean the wire connection and then re-solder. When the solder is being run out, it will be noticed that the lead is absolutely black.

I have also found it advisable to do the rest of the valves at the same time, as I have had the same trouble with all of them .-- A. LINTER, REDHILL.

I.F. Transformer Short

HAVING made the usual tests for a leakage to earth of the H.T. current in a Ferranti 1934-5 Lancastria receiver, I finally traced a dead short between the secondary and primary windings of the second I.F. transformer.

Opening out the can, expecting to find the leads from the windings to the tags twisted together, which is the usual cause of this fault, I was surprised to find a piece of wire (the same material as the secondary windings) was between the layers of the secondary, continuing for one turn round the former and then entering the layers of the primary. On cutting this wire the short disappeared and after refitting the transformer and re-ganging the set, it again worked perfectly

The only reason I can give for the break down was that the end of the short piece of wire must have pierced the insulation of the primary when the coil was made, and due to the constant vibration the other end of the wire finally punctured the insulation of the secondary .- G. JAMES, WALSALL.

Modifying a K-B 333A

KOLSTER-BRANDES 33A receiver had never really given satisfactory results since it was purchased. This was put down to the band-pass circuit which this receiver incorporates, so an attempt was made to find out if the circuit would lend itself to modification.

The first half of the band-pass circuit was cut out and the aerial transferred via a small capacity fixed condenser to the grid end of the coil, this resulting in a considerable increase of signal strength, but it was still felt that a bigger reserve was desirable.

The plate circuit of the S.G. valve consisted of an H.F. transformer with a tuned secondary and reaction winding, and as it was not possible to alter the transformer, it was decided to alter the circuit to a parallel fed arrangement. This was carried out, using an H.F. choke in the S.G. plate circuit and coupling via a fixed condenser to the tuned secondary, which, of course, was retained.

The set was now extremely lively and while the selectivity was not exactly razor sharp, the improved performance of the receiver more than justified anything lacking in that respect, and our customer was very satisfied with the alteration. R. A. COATES, WHITBY.

About the Philco 56

NOTED with interest a paragraph about a Philco 56 model, in which the writer suggested changing the two 36E valves round when signals disappeared below 260 metres. The best way of curing the trouble permanently is to lessen the bias on the oscillator valve so that it oscillates more freely, as the trouble can nearly always be traced to this valve ceasing to oscillate.

In other cases the cathode winding in the oscillator coil gets too close to the main coil, when the unit should be removed and the windings separated with paxolin or rubber.—R. Young, Slough.