McMICHAEL TWIN-SPEAKER SUPERHET

Circuit.—The combined first detector oscillator valve, AC/TP met. (V1), is preceded by a single tuned aerial circuit which is coupled to a special input filter. The oscillator circuit is conventional for an H.F. pentode triode valve and coupling to the next valve is by band-pass I.F. transformer (for frequency see special notes). Bias for the pentode section is by A.V.C. and cathode resistance. and cathode resistance.

The first I.F. valve, AC/VP1 met. (V2), is coupled to a second I.F. valve, which is another AC/VP1 met. (V3), by a second band-pass I.F. transformer and V3 is simi-

larly coupled to the second detector.

An AC/HL met. (V4) operates as a muting valve on radio and a first L.F.

muting valve on radio and a first L.F. amplifier on pick-up reproduction.

The output valve is an AC/2Pen/DD (V5) which is stabilised by a grid resistance and tone compensated by a condenser between the anode and cathode as well as by tone control condenser and resistance.

Mains equipment consists of transformer with H.F. by-pass condensers, voltage doubler rectifier and a 1,200-ohm speaker

VALVE READINGS No signal. Full sensitivity (switch down).

Valve.	Type.	Electrode.	Volts.	M.a.
1	A.C. /TP met. (9)	anode	215	*
	211007 (47)	aux. grid	170	
		osc. anode	112	
2	A.C./VP1 met. (7)	anode	250	3.9
	11100. (1)	aux. grid	150	
3	A.C./VP1 met, (7)	anode	250	3.9
		aux. grid	150	
4	A.C./HL met. (5)	anode**		
5	A.C.2 Pen.	anode	250	37
	DD (7)	aux. grid	240	6

* Set is unstable with long meter leads for curren

tests.

** Very high resistance in circuit, no appreciable voltage will be recorded.

field in the positive H.T. lead for smoothing.

The 7,500-ohm field of the other speaker is in series with a 1,500-ohm resistance across the smoothed H.T.

Special Notes.—There is a sensitivity

Special Notes.—There is a sensitivity switch at the back of the chassis.


The first models of this receiver used an intermediate frequency of 406-410 kc. but later models are tuned to 428 kc. These models are marked by a splash of orange paint on the I.F. transformer cans.

Where several "whistles" are encountered on the first models the I.F. frequency may be increased to 428 kc. This involves retracking the oscillator and (in the case of early models which have orange and blue tracking condensers mounted underneath

(Continued on opposite page.)


RESISTANCES						
R.	Purpose.	Ohms.				
1	Harmonic suppressor V1 osc.	2,000 (1)				
2	Series with V1 suppressor grid	2,000 (1)				
3	Decoupling V1 grid	1 E mage (1)				
2 3 4 5 6 7 8	Part of V1 aux, grid ptr	10,000 (1)				
5	Part of V1 aux. grid ptr	20,000 (1)				
6	Decoupling V1 anode					
7	Decoupling V1 osc. anode					
8	V2 cathode bias					
9	Decoupling V2 grid					
10	V2 and V3 cathode bias					
11	V3 cathode bias					
12	Part of A.V.C. ptr					
13	Decoupling V3 grid	$.5 \text{ meg} \left(\frac{1}{4}\right)$				
14	Part of A.V.C. ptr.	$.5 \text{ meg} \left(\frac{1}{4}\right)$				
15	H.F. stopper from diode	100,000 (1)				
16	Diode load					
17	Part of bias ptr					
18	V5 grid stabiliser	50,000 (1)				
19	Voltage control of V4					
20	Part of bias ptr					
21	Part of bias ptr					
22	V1 osc. grid leak					
23*	Across P.U. connections					
24	V5 anode stabiliser					
25	Voltage drop to L.S. field 2					
	L.S. No. 1 field					
	L.S. No. 2 field	7,500				
Bra	Bracketed figures denote wattage.					

* Used only in models with P.U. sockets instead of




The Twin-speaker Superhet by McMichael Radio, Ltd., is a "de luxe" type of table receiver for A.C. mains operation.


CONDENSERS					
C.	Purpose.	Mfd,			
1	Decoupling V1 grid	.03 (450)			
2	Decoupling V1 anode	.1 (450)			
2A	Decoupling V1 grid	.01 (450)			
3	Decoupling V1 osc. anode	1 (450)			
3 4	Decoupling V1 aux. grid	.1 (450)			
- 5	Decoupling V2 grid	.03 (450)			
6	V2 cathode	.1 (375)			
7 8	V3 cathode	.1 (375)			
8	Decoupling V3 grid	.03 (450)			
9	Decoupling A.V.C. line IF feed to A.V.C. diode				
10	IF feed to A.V.C. diode	.0001			
11	H.F. by-pass from diode	.0001			
12	V5 cathode	25 (25)			
13	Tone control circuit	05 (450)			
14	L.F. coupling to V5 grid	.002			
15	V4, V5 L.F. coupling on gram	.01			
16	V1 cathode	.0002			
17	V1 osc. grid reservoir (or .0005)	.0002			
18	Balancing condenser for aerial filter.	.0003			
19	Balancing condenser for aerial filter.	.0002			
20	V2, V3 aux. grid by-pass	.5			
21	H.T. smoothing el	8 (440)			
22	H.T. smoothing el	8 (440)			
23	Tone compensating V5 anode				
24	Voltage doubler condenser	4 (400)			
25	Voltage doubler condenser	4 (400)			
26	H.F. by-pass from mains	.002 (450)			
27	H.F. by-pass from mains	.002 (450)			
	Bracketed figures denote working voltages.				



The McMichael circuit is designed round a triode - pentode frequency-changer, two intermediate frequency amplifiers, a muting valve and a combined double-diode and pentode valve.

more information remember www.savoy-hill.co.uk





Above is the top plan of the McMichael Twin-speaker Superhet chassis. In early models the medium- and long-wave tracking condensers, were accessible only from underneath (see Special Notes).

The complete assembly can be removed from the cabinet and the underside of the set chassis can be revealed by pivoting it on two rear screws. Left, is the view of the "opened" assembly.

(Continued from previous page.)

the upper chassis on the aerial filter side of the switch) special insulated 12 in. box spanners are obtainable from the makers to allow this adjustment to be made without removing the chassis.

Later models have tracking condensers as shown in the diagrams. These are adjustable from above.

Quick Tests. — Voltages between the following points and chassis :—

Positive plate of rectifier, 370 volts (H.T. unsmoothed).

Left-hand speaker looking from the back and counting tags from the left: (1) and

(2) 250 volts; (3) 248 volts, H.T. smoothed;
(4) 240 volts, V5 anode; (5) 370 volts, H.T. unsmoothed.

Left-hand tag on right-hand speaker, 200 volts.

Removing Chassis. — Remove control knobs (grub screw) and wave-change switch lever by undoing central screw

Remove four holding screws from underneath and slide chassis out.


To reveal the complete chassis, remove two screws from underneath flange in front between the two chassis and remove the two front of the three screws at each side. Pivoting the top chassis on the two rear screws, turn it over till the chassis is

revealed as in the diagram. There are stops to hold it in this position.

General Notes.—The receiver can conveniently be tested and the components examined without removing the chassis but if any alteration or replacement has to be made it is advisable to remove the chassis completely.

Replacing Chassis.—Return the upper chassis to its original position, replace the six Liding screws and slide the chassis carefully into position, taking care that the wave-change switch spindle does not foul the escutcheon.

Replace the four holding screws and the knobs.



ATLAS TYPE B345 BATTERY SET

The tilting-dial is a distinguishing feature of the Atlas B345 receiver produced by H. Clarke & Co. (Manchester), Ltd.

Circuit.—The H.F. valve, VP2 met. (V1), is preceded by a tuned secondary H.F. transformer with a medium-wave choke in series with the primary to prevent break through on the long waves.

Volume is controlled by a potentiometer across the G.B. battery. Coupling to the next valve is by another tuned secondary transformer.

The second valve, SP2 met. (V2), operates

as a leaky-grid detector with reaction, and is coupled to the output valve by an L.F. choke, damped by the resistance R3, and condenser and grid leak filter.

The output valve, PM22A (V3), is tone compensated by a condenser across the primary of the output transformer.

Special Notes.—Battery voltages are:—H.T.+ (red), 120 v.; H.T.+ (yellow),

80 v.; G.B.+ (grey); G.B.- $4\frac{1}{2}$ (yellow); G.B.- 9 (white).

The volume control resistance acts as a bleeder for the G.B. battery.

Quick Tests.—These are best performed

Quick Tests.—These are best performed by noting the clicks during valve tests. Removing Chassis.—Turn dial to hori-

Removing Chassis.—Turn dial to horizontal position, remove knobs (grub screw), three screws underneath and undo speaker leads from transformer. Lift the chassis clear of the back stops.

General Notes.—In some models the L.F. choke was omitted, C10 was .05 mfd., and the switch was in the L.T.—lead.

There is no trimmer for the aerial coil on the gang condenser—instead there is a variable type mounted on the front of the chassis.

type mounted on the front of the chassis.

There are three terminals on the V2 coupling choke, of which the one nearest the end is used only as an anchorage

end is used only as an anchorage.

The Cord Drive.—To reach the cord inside the dial, remove the two screws at the ends of the chromium-plated frame, taking care not to lose the distance pieces inside.