# **INVICTA** 11P2

Three valve, plus rectifier, two waveband superhet portable with frame aerial and for 200-250 volt A.C. or D.C. supplies. Made by Invicta Radio, Ltd., Cambridge.

the medium wave grid coil of V1, circuit in C26, R12. the frequency-changer. For long waves a "loading coil" is switched in, the lytics, C23 being a paper tubular forming frame remaining in circuit for signal an efficient H.F. by-pass. As usual pick-up. An external aerial connection with A.C./D.C. sets, the rectifier, V4, goes straight to V1 grid via C1.

and earth connections from the mains.

The oscillator section is parallel-fed tuned anode with grid coupling coils. There are no padding condensers as the oscillator section of the gang is specially shaped.

Permeability - adjusted I.F. transformers link up V2, the I.F. amplifier, and V3, the combined double diode and output pentode.

Demodulation diode arrangements are straightforward with R5, C21, C22 forming an H.F. filter, and R6, the load, feeding L.F. to R8, the volume control, via a D.C.-isolating capacity, C19.

point as the signal diode being isolated for D.C. purposes by C20.

The pentode section has a shunt Fircuit.—The frame winding forms tone corrector, C30, and a variable tone

Smoothing is by choke and two electrois a half-wave type and all the heaters C8 decouples the A.V.C. to V1 and are series run from an adjustment re-

C8 and C9 together isolate both aerial | sistance, C28 and C29, with two chokes to | VALVE READINGS filter out mains noise.

> The speaker is a P.M. type with 2-ohm speech coil.

### GANGING

I.F. Circuits.—Tune to M.W. maximum. Inject 467 kc. to V1 grid and adjust I.F. cores for maximum, reducing input as circuits come into line.

M.W. Band.—Tune to 200 metres and inject this wavelength by means of a loop of wire brought near to the frame aerial. Adjust T1 and T2 for maximum.

Check at 550 metres and compromise a little if necessary.

L.W. Band.—Tune to 1,300 metres The A.V.C. diode is fed from the same and inject this signal as on M.W. Adjust T3 and T4 for maximum.

### RESISTANCES

R	Ohms	R	Ohms	
1	 20,000	9	 50,000	
2	 50,000	10	 250	1
$\frac{2}{3}$	 50,000	11	 1 meg.	1
4	 200	12	 20,000	1
5 6	 110,000	13	 1 meg.	1
6 .	 510,000	14	 100	1
7	 200	15	 100	1
8	 1 meg.	16	 780	1

V	Type	Electrode	Volts	Ma.
1	ЕСН3	Anode	242	2.8
		Screen	95	4
		Osc. anode	90	2.3
1		Cathode	1.8	9.1
2	EF9	Anode	242	7
		Screen	95	2.2
		Cathode	1.8	9.2
3	CBL1	Anode	230	37.5
		Screen	242	6
ļ		Cathode	11	43.5
4	UR3C	Anode	230 A.C	
I	Dial lamps, 6.2	v., .3 amp.		

### CONDENSERS

10	mjus.		Mijas.
1	5 mmfds.	19	 .005
2	1	20	 20 mmfds.
3	150 mmfds.	21	 100 mmfds.
4	100 mmfds.	22	 100 mmfds.
8	1	23	 .1
9	05	24	 8
12	1	25	 16 + 8
13	70 mmfds.	26	 .025
14	70 mmfds.	27	 20
15	60 mmfds.	28	 .1
16	80 mmfds.	29	 .1
18	1	30	 .003
I			

## replacements, or supplies of materia run short. Here are recommendations. drawn from my own experience, on how these difficulties should be tackled.

War-time Economies in

the Service Shop

TN these times, service engineers often

have difficulty in obtaining correct

When erecting new aerials, use an insulator on pole tops to act as a block for the sliding halvard wire instead of the usual pulley. This will not rust, and is much cheaper and simpler. If overhauling an existing system, the old aerial wire may be good enough when painted to do for the halvard or stand-off wire.

Often it is impossible to get an exact type of valve or equivalent in the same base, but there are others of American or British pattern with a different base. In the case of H.F., I.F. and detector types the valveholder in the set must be changed. With L.F., power and rectifier valves leave the old valve base, fit leads to this and wire up to a new type base to fit the substitute valve. This extra base may be screwed to inside the cabinet until the proper valve is obtainable.

If there is any interaction after these alterations it is usually due to the longer leads, and can be cured in most cases by using screened wires (or wrapping earthed tinfoil round them).

In the case of substitution of H.F. valves great care should be taken when comparing characteristics, as only slight variations will prevent correct working in some cases. L.F. types are not so troublesome in this respect.


Transformers and coils are all rewound by the specialist firms, and in all cases have been found as satisfactory as new components.

Condensers are usually easily obtainable, but in the case of very small values remember that two short lengths of insulated wire twisted will give sufficient capacity. This may be checked on a bridge meter. In the case of shorting trimmers, dismantling and cleaning will often effect a cure.

Variable resistances, such as volume controls, may be cleaned after dismantling, and more tension put on the spring rotary part. If the carbon track is in a bad way, it is sometimes possible to obtain these units from the manufacturers without getting the whole control. Wire resistances can usually be rewound by an engineer once he recognises the type of resistance wire.

Switches seldom actually break and

Continued on opposite page



The UP2 is a small A.C./D.C. superhet portable. The V1 grid coil for M.W. forms the frame aerial. There are no oscillator padding condensers because the gang vanes are specially shaped. There is a mains H.F. filter.