1941

PILOT 455

Four valve, plus rectifier and barretter, three waveband table model superhet for operation from A.C. or D.C. mains of 200-250 volts. Made by Pilot Radio, Ltd., 31-33, Park Royal Road, London, N.W.10.

Circuit.—On each waveband transformer coils link the aerial to VI. the frequency-changer. The primaries given, as these vary considerably with are switched and each secondary has a the supply voltage. The valves are: trimmer. An unusual feature is that V1, 6K8G; V2, 6U7G; V3, 6Q7G; the S.W. grid circuit becomes in series V4, 25A6G; V5, 25Z6G; V6 (barretter), on M. and L.W. It does not then, of 304. Pilot lamp, 7.3 v., .25 amp. course, have any tuning effect. A.V.C. 12 mm. type. is applied on M. and L.W. only.

The oscillator section is very similar, although in this case the S.W. trimmer remains operative on M. and L.W. of the padder T9, on L.W.

Both I.F. transformers are trimmer double-diode triode.

Only one diode is used, the volume control forming the diode load for both demodulation and A.V.C. A jack provides a pick-up connection. The selfbiasing triode section is resistancecapacity coupled to V4, the output pentode, the arrangement including a shunt tone control.

H.T. is drawn, through a conventional smoothing arrangement, from a half-wave rectifier, V5. This is actually a full-wave type with strapped

The valve heaters are series run through a barretter and the pilot lamps. These have a shunt safety resistance. Mains noise filter chokes are included in the supply leads.

Valves.-A table of voltages is not

GANGING

I.F. Circuits.—Inject 451 kc. to VI Regenerative coupling is inductive on grid and adjust I.F. trimmer for maxi-S. and M.W., but capacitative, by means | mum, reducing the input as the circuits come into line.

S.W. Band.—Inject 16.8 m. to aerial. tuned, although the first has iron-core tune to this wavelength, and adjust coils. V2 is the I.F. amplifier and V3 a T1 and T2. Set T1 at the peak first obtained from full out. Padding (T3)

> M.W. Band.—Tune to 214 m., inject this wavelength and adjust T4 and T5. Tune to and inject 500 m. and pad with

L.W. Band.—Tune to 1,100 m., inject this wavelength and adjust T7 and T8. Tune to and inject 1.900 m. and pad with T9.


RESISTANCES

R	Ohms.	R	Ohms.
1	 33,000	9	 1 meg.
2 3	 33,000	. 10	 9.5 meg.
3	 270,000	11	 1 meg.
4	 4,700	12	 470
5	 47,000	13	 270,000
6	 1 meg.	14	220
7	 220	15	 100
8	 47,000	16	 120
'	 ,	,	

CONDENSERS

\boldsymbol{c}		Mfds.		Mfds.
4		.00006	22	 25
6	•• ′	.00015	23	 .002
9		.05	24	 8 + 16
2		.05	25	 .0004
3		.006	26	 .01
;		.05	27	 8
		.05	28	 .0001
8		.00015	27 28 29	 .025
)		.001	30	 .05
L		.01	31	 .025
			32	 .1

All trimmers are accessible from the top of the Pilot chassis. The aerial trimmers are on the rear face of the coil can.



Wattage of Replacement Resistors

WHEN replacing resistors it must be i.e., the wattage must be right. remembered that a suitable integral part of the process of breaking related to voltage $(C = \frac{E}{R})$ we can also down voltages by the introduction of resistances. The power expended in the say that $W = C^2 \times R$ or $W = \frac{E_2}{P}$. resistance is developed in the form of heat.

The resistance used in any particular position must be of such a design that the current flowing, hence W=C2×R is the heat is dissipated fast enough to the formula most useful. For example, prevent an undue rise in temperature—

Wattage is the product of current and wattage is just as important as a suitable voltage, i.e., $W = C \times E$. Since, in any ohmage. The production of heat is an particular circuit, C and R are definitely

> In radio work, the service data usually give us the value of the resistance and

> > Continued on opposite page

