NUMBER EIGHTY-ONE 'TRADER' SERVICE SHEET

AERODYNE 'BLUEBIRD'

MODEL A FOR A.C. MAINS

A DROITWICH filter is fitted in the Aerodyne "Bluebird" receiver, and provision is made for a gramophone pick-up and an extension speaker. The circuit consists of a variable-mu H.F. pentode, a triode detector and a pentode output valve. Volume and reaction controls are fitted.

Model A, with which we deal, is for A.C. mains of 200-250 V, 50 cycles. There is also an A.C./D.C. type (Model

CIRCUIT DESCRIPTION

Two alternative aerial connections (A1 via series condenser C2 and Droitwich wave-trap L1, C3, C17, and A2 via series condenser C1) to coupling coils L2, L3. Single tuned circuit L4, L5, C18 precedes first valve which is a variable-mu pentode (V1, Mullard metallised VP4B) operating as H.F. amplifier. Gain control by variable resistance **R3** which varies G.B. applied.

Tuned-anode coupling by L7, L8, C20 to triode detector (V2, Mullard metallised 354V) operating on grid leak

system with C7 and **Ř6.** Reaction is applied from anode by coil L6 and controlled by variable condenser C22. Provision for connection of gramophone pick-up in grid circuit. H.F. filtering in anode circuit by choke L9 and by-passes C9, C10.

Resistancecapacity coupling by R8, C11, and R10 to output pentode (V3, Mullard Pen4VB). Fixed tone correction in anode circuit by condenser C12. Provision for connection of low impedance external speaker across secondary of internal speaker transformer **T1**.

H.T. current is supplied by I.H.C. full-wave rectifying valve (V4, Micromesh or Brimar R2 or R3). Smoothing by speaker field winding L12 and electrolytic condensers C14, C15. Mains aerial connection by C16.


COMPONENTS AND VALUES

	Condensers		(μF)
C1 C2	Aerial series condensers	{	0.0001
C ₃	Droitwich wave-trap tuning		0.003
C ₄	Vi S.G. by-pass		0.1
C ₅	Vi cathode by-pass		0.1
C6*	Vr anode decoupling	'	1.0
C7	V2 grid condenser		0.00005
C8	V2 anode decoupling		1.0
C9	Ve and HE become	5	0.0005
Cio	V2 anode H.F. by-passes	٦	0.0005
CII	L.F. coupling to V ₃		0.01
C12	Tone corrector		- 0.01
C13*	V3 cathode by-pass		25.0
C14*	H.T. smoothing	1	8.0
C15*	J	ſ	8.0
C16	Mains aerial coupling		0.0002
C17‡	Droitwich wave-trap tuning	ζ	0.002
C18†	Aerial circuit tuning		0.0005
C19‡	Aerial circuit trimmer		
C20†	VI anode circuit tuning		0.0005
C21‡	VI anode circuit trimmer		
C22†	Reaction control		0.0003
* F	Electrolytic † Variable †	Pre	set

* Electrolytic	† Variable	‡Pre-set
----------------	------------	----------

Resistances	Values (ohms)
R1 R2 R3 V1 S.G. H.T. potential divident R4 V1 gain control R5 V1 anode decoupling R6 V2 grid leak V2 anode decoupling R8 V2 anode load R9 V3 grid H.F. stopper R10 V3 grid resistance R11 V3 G.B. resistance R11 V3 G.B. resistance R12 R2 R3 R4 R4 R4 R4 R4 R4 R4	15,000 20,000 8,000 100 1,000,000 20,000 50,000 500,000 140

	Other Components	Values (ohms)
L1 L2 L3 L4 L5 L6 L7 L8 L9 L10 L11 L12 T1	Droitwich wave-trap coil Aerial coupling coils	2·2 0·75 14·25 3·5 13·0 6·5 3·5 14·5 20·0 1·75 0·05 1,500·0 0·3 26·0 0·05 440·0
S4.	Mains switch, ganged R3	



For more information remember www.savoy-hill.co.uk

DISMANTLING THE SET

Removing Chassis.—To remove the chassis, remove the back (seven roundhead wood screws), four control knobs (pull off), the two round-head wood screws holding the tuning scale to the cabinet front, and the three bolts (with washers) holding the chassis to the cabinet bottom. The chassis can now be withdrawn to the extent of the speaker leads, which is sufficient for normal purposes.

To remove the chassis entirely, unsolder the leads from the speaker terminal panel. When replacing, connect the leads as follows, numbering them from left to right, with the transformer pointing to the bottom right-hand corner of the cabinet: 1 and 2 joined together, red; 3, blue; 4, black.


Removing Speaker.—If it is necessary to remove the speaker, slacken the four clamps holding it to the sub-baffle and remove the round-head wood screw (with washer).

VALVE ANALYSIS

Readings of valve voltages and currents given in the table below were taken with the receiver operating on 220V A.C. mains, with the transformer on the 230 V tap. The volume control was at maximum, while reaction was at minimum, and there was no signal input. Voltages were measured on the 1,200 V scale of an Avometer, with chassis as negative.

Valve	Anode Volts	Anode Current (mA)	Screen Volts	Screen Current (mA)
Vr VP ₄ B	210	7.4	135	2.7
V2 354V	85	2.8		P. Company
V ₃ Pen ₄ VB	210	30.0	230	3.4
V4 R3	265†			-

†Each anode, A.C.



Plan view of the chassis. A valve-holder is used to provide sockets for mains voltage adjustment.

GENERAL NOTES

Switches.—\$1-\$3 are the waveband switches, in a single unit, and they are all closed on the M.W. band and open on the L.W. band. Note that **\$1** and **\$2** each have one common contact.

\$4 is the Q.M.B. mains switch, ganged with the volume control **R3**.

Coils.—L1 is the Droitwich wave-trap coil, mounted beneath the chassis. L2-L8 are in two screened units on the chassis deck, and L9 is an H.F. choke, beneath the chassis.

Scale Lamp.—This is an Osram M.E.S. type, rated at 6.2 V, 0.3 A.

External Speaker.—Two sockets for a low resistance external speaker are provided on a paxolin strip at the base of the speaker transformer. The resistance

of the speaker should be about 2 O. Condensers C4, C8, C10.—These are all hidden beneath the paxolin component panel in the middle of the underside of the chassis. C4 is a tubular type, and C10 a flat mica type, mounted beneath the paxolin panel, while C8 is a 1μ F paper type secured to the chassis itself. The positions of these condensers are indicated in our under-chassis view by dotted lines.

Condensers C14, C15.—These are two $8\mu F$ dry electrolytics in one unit beneath the chassis. There is a common negative (black) lead, and two positives (red). The red lead going to a heater socket of the V4 valve-holder is the positive of C14.

Condenser C17.— This tunes the Droitwich filter, and is adjustable through a hole in the side of the chassis.

Under-chassis view. C4, C8 and C10 are beneath the component panel in the centre. C17 is adjusted through a hole in the side of the chassis.
