

OTHER COMPONENTS		Approx. Values (ohms)	Locations
L1	S.W. aerial coup.	—	A1
L2	—	—	A1
L3	Aerial tuning coils	3.5	A1
L4		13.5	A1
L5	Oscillator tuning coils	5.5	G3
L6		7.5	F3
L7	Oscillator reaction coils	29.5	G3
L8		2.8	F3
L9	1st I.F. trans.	9.0	A2
L10		9.0	A2
L11	2nd I.F. trans.	9.0	B2
L12		9.0	B2
L13	Speech coil	7.0	D4
L14		2.6	—
L15	Mains R.F. filter chokes	7.0	D4
L16		7.0	D4
L17	Frame aerial	—	—
T1	O.P. trans.	310.0	B1
S1-S9	Waveband switches	—	F3
S10, S11	Mains sw., g'd.	—	D3
F1, F2	500mA fuses	—	C2

VALVE ANALYSIS


Valve voltages and currents given in the table below are those derived from the manufacturers' information, whose receiver was tuned to 500 m and was operating under "no signal" conditions from 200 V A.C. mains. Voltages were measured with a 1,000 ohms-per-volt meter, chassis being the negative connection.

Valve	Anode		Screen		Cath.
	V	mA	V	mA	
V1 OM10	140 Oscillator	1.6 6	50	3.25	—
V2 OM6	140	1.8 3.4	50	1.15	—
V3 OM4	20	*	—	—	—
V4 332Pen	220	30.0	140	2.3	6
V5 OM1	210†	—	—	—	230



*Very low reading. †A.C. voltage.

DISMANTLING THE SET

Removing Chassis.—Remove five self-tapping screws (with washers), withdraw frame aerial plugs, and remove back and base cover; Remove the four control knobs (recessed screws), withdraw speaker plugs, remove chassis guard strip insulating rear member (two self-tapping screws), remove two screws thus revealed holding ends of chassis to moulded ribs on cabinet, and remove one further screw from top of scale assembly.
When replacing, note that two smaller knobs go on the centre spindles (that with a white spot on the right), and see that the heat deflector is in position over the ballast resistor. It is a shaped piece of cardboard which slides along a moulded rib on the roof of the cabinet.




Under-chassis view. The waveband switch units are indicated by numbers 1 and 2 in diamonds.



Left: Waveband switch units. Right: Plan view of the chassis.

CIRCUIT ALIGNMENT

I.F. Stages.—Switch set to M.W., turn gang to minimum and volume and tone controls fully clockwise. Connect output of signal generator, via an 0.1 μF capacitor, to control grid (top cap) of V1 and chassis. Feed in a 470 kc/s (688.3 m) signal and adjust the cores of L13 (location reference F4), L12 (B2), L11 (G4) and L10 (A2) for maximum output. Repeat these adjustments.
R.F. and Oscillator Stages.—Turn gang to minimum and check that the cursor coincides



Tuning drive, viewed from rear.

with the line marked "MIN" at top left of tuning scale. This can be adjusted if necessary by slackening the two grub screws securing the drive drum to the gang spindle and rotating the drum. Transfer signal generator leads, via a dummy aerial, to A and E sockets.
M.W.—Switch set to M.W., tune to vertical line marked "M" at top of scale, feed in a 193.6 m (1,550 kc/s) signal and adjust C34 (G3) and C30 (G3) for maximum output.

L.W.—Switch set to L.W., tune to vertical line "L" at top of scale, feed in a 1,875 m (160 kc/s) signal and adjust C35 (F3) for maximum output.
S.W.—Switch set to S.W., tune to vertical line "S" at top left of scale, feed in a 16.67 m (18 Mc/s) signal and adjust C33 (G3) and C29 (G3) for maximum output, C33 being set to the lower capacitance peak of the two possible maximum output positions. Tune set to vertical line "S" at top right of scale, inject a 50 m (6 Mc/s) signal and adjust the core of L5 (A1) for maximum output. Repeat the above adjustments to C33 and L5 until calibration is correct at both ends of band. Tune set to vertical line "S" at top left of scale and re-adjust C29 while "rocking" the gang to obtain optimum results.

GENERAL NOTES

Switches.—S1-S9 are the waveband switches, ganged in two rotary units beneath the chassis. These are indicated in our underside view of the chassis by the numbers 1 and 2 in diamond surrounds, and shown in detail in the diagrams inset beside the plan view drawing, where they are drawn as seen when viewed from the rear of an inverted chassis. The table below gives the switch positions for the three control settings, starting from the fully anti-clockwise position of the control knob. A dash indicates open, and C, closed.

Switch	S.W.	M.W.	L.W.
S1	C	—	—
S2	—	C	—
S3	—	—	C
S4	C	—	C
S5	—	C	—
S6	C	—	C
S7	—	—	C
S8	—	C	—
S9	C	—	—

S10, S11 are the Q.M.B. mains switches, ganged with the volume control R9.
External Speaker.—Two pairs of sockets are provided at the rear of the chassis for the connection of the internal speaker and a low impedance (about 3 Ω) external speaker. A third pair of sockets is unused in this A.C./D.C. receiver, except as bearers for internal connections.
Scale Lamp.—This has a large clear spherical bulb and an M.E.S. base, and is rated at 8 V, 0.2 A. Our specimen was marked 8 V, 1.6 W.
Drive Cord Replacement.—Forty inches of high grade flax fishing line, plaited and waxed, is required for a new drive cord. It should be run as shown in the sketch (col. 2), where it is drawn as seen from the rear when the gang is at maximum capacitance.

Model 494U

The circuit of the 494U is basically similar to that of the 501U, but there are two main differences. First, the oscillator H.T. feed circuit is different; and second, the tone control is different. The difference in the oscillator circuit is that the reaction coils are series fed. The bottom of L9 goes to the screen grids of V1 and V2 instead of to chassis, and R5, C13 are omitted. C14 was 0.01 μF, but otherwise component values were unchanged.
The tone control circuit R13, C21 was connected between V3 anode and cathode, and C21 was 0.01 μF. R14 went to the top of R12, which was 470 kΩ. C22 was connected in parallel with R12. R11 was 680 kΩ.